

Operating Instructions



Island Oasis

Before operating this machine, please ensure that the drain hose is connected underneath the unit and that you have the dispenser in place to catch the water from the hose. Also, ensure you have the machine plugged into a dedicated 20-amp outlet.

1. Plug the unit in, fill the transparent acrylic hopper with ice, and securely replace the lid. Please note that a small straw will be depressed when the lid is properly placed. The unit will not work if that straw is not depressed. The red light will indicate that the lid is on correctly.
2. You can use the preset buttons, which automatically shaves and blends your mix based on a 17 oz individual drink portion. If you choose this option, press:
 - Button #1 = 1 drink
 - Button #2 = 2 drinks
 - Button #3 = 3 drinks
 - Follow the drink mix package directions to measure the proper amounts of liquor and mix.
3. You may choose to have different size portions. If so, you first need to pour your mixture into the pitcher with or without alcohol, then manually press:
 - Shave button: Until the desired ice fills the pitcher, then press
 - Mix button: To blend the drink. If the mixture is too thick, add water/or liquor to dilute and press mix again. Ensure the lid on the pitcher is on correctly, or the blender will not operate.

Trouble Shooting:

- Turn off the unit, then push the reset button on the back of the machine and try again.
 1. Remove all large chunks of ice.
 2. Add hot water to free up the ice scrambler.
 3. Press the clear reset button on the right side of the machine.
 4. Make sure the lid is pressing down the white rod for contact.
 5. Make sure you have a red light on the stop button.
- Do NOT put large pieces of ice in the hopper – it will jam the machine
- Cubed ice is required. If using bagged ice, make sure it is broken into small pieces, and you might want to add 5 oz of water to the bag to ensure the ice is wet.
- Dry, powdery ice will freeze the ice scrambler and trip the machine.

Cleaning:

Rinse out the pitchers and remove all the ice from the machine. Scoop out excess ice and then use the manual shave button on the control panel to shave any remaining ice in the ice hopper.

**For any questions or concerns, be sure to contact us immediately.
Thank you for your business!**

1155 Route 9
Wappingers Falls, NY
(845) 298-0011



1 Precision Road
Danbury, CT
(203) 744-2295